


SPARE PARTS CATALOGUE
: SPREADER XL

Spare Parts List

SPARE PARTS LIST



REF.	PART NO.	DESCRIPTION	REMARK	QTY.	KIT
1	590380601	TUBE	436-00.600.01	1	
2	590380701	LEVER	436-00.600.02	1	
3	590380801	SCREW	436-00.600.06	1	
4	581842401	NUT	58-18.424.01	1	
5	590380901	CLIP	436-00.600.07	1	
6	590381001	ROPE	436-00.600.17	1	
9	590381201	LOCK	436-00.600.28	1	
10	590381301	SPRING	436-00.600.33	1	
11	590381401	CASE	436-00.600.34	1	
14	520401101	SCREW	1625-00.600.16	1	
15	590381701	WHEEL	436-00.600.42	1	
16	590381801	HUB CAP	436-00.600.45	1	
17	590381901	BUSH	436-00.600.47	1	
21	590382301	GEAR WHEEL	436-00.600.63	1	
22	582284301	CRANK	436-00.600.68	1	
23	590382401	DISC	436-00.600.73	1	
24	590382501	BUSH	436-00.600.78	1	
25	590382701	WHEEL	436-00.600.83	1	
26	590383201	DEFLECTOR	436-00.600.88	1	